

## AD 2. AERODROMES

### FYLZ AD 2.1 AERODROME LOCATION INDICATOR AND NAME

FYLZ - Luderitz Aerodrome

### FYLZ AD 2.2 AERODROME GEOGRAPHICAL AND ADMINISTRATIVE DATA

1.	ARP coordinates and site at AD	264107S 0151444E
2.	Direction and distance from (city)	SE 5 NM from Luderitz
3.	Elevation/reference temperature	457 FT/139 M
4.	MAG VAR/annual change	17° W (2016)
5.	AD administration, address, telephone, telefax, telex, AFS	Namibia Airports Company Luderitz P.O.Box 2307, Walvis Bay, Namibia Tuhafeni Hishitelwa: +264 81 408 3328 Administration Tel: +264 63 202035 ATC Tel: +264 63 703590/ 202228 Additional ATC Tel: +264 63 703591 ATC Fax: +264 63 703599 Telefax: +264 63 202037 Controlling AD Tel S/B : +264 63 202035 Fax: +264 64 202037 Email: <a href="mailto:Hishitelwat@airports.com.na">Hishitelwat@airports.com.na</a> Telex: Nil info available AFS: Nil info available
6.	Types of traffic permitted (IFR/VFR)	IFR/VFR
7.	Remarks	Public aerodrome, designated port of entry/exit

### FYLZ AD 2.3 OPERATIONAL HOURS

1.	AD operator	MON-FRI: 0600-1500, SAT: 0700-1300, SUN: 0800-1200 24 HR notification for AFT HR OPS, except MEDEVAC and Mercy flight
2.	Customs and immigration	AVBL on request Customs Tel: +264 63 202259 / 202190 Immigration Tel: +264 63 203440
3.	Health and sanitation	AVBL on request Tel: +264 63 202446
4.	AIS briefing office	Nil services
5.	ATS reporting office (ARO)	Nil services
6.	MET briefing office	Nil services
7.	ATS	MON-FRI: 0600-1500, SAT: 0700-1300, SUN: 0800-1200
8.	Fuelling	MON – FRI: 0600 – 1500 SAT: 0700-1300 SUN: 0800-1200 Public HOL: Call out.

9.	<i>Handling</i>	Nil services
10.	<i>Security</i>	24 HRS
11.	<i>De-icing</i>	Nil services
12.	<i>Remarks</i>	Except in the case of emergency or with prior permission no ACFT may take off or land outside AD OPR HR.

### FYLZ AD 2.4 HANDLING SERVICES AND FACILITIES

1.	<i>Cargo-handling facilities</i>	Nil info
2.	<i>Fuel / oil types</i>	AVGAS, Jet A1
3.	<i>Fueling facilities /capacity</i>	Southern Energy Company P.O Box 1228 Walvis Bay  Tel/Fax: +264 63 203605 Refueler: Gregory Bock, Cell: +264 81 150 2462 Werner Losper Cell +264 81 735 5758 Office: +264 63 203605 SDBY cell phone: +264 81 142 9958 <b>Controlling Office</b> Tel: +264 64 203951 / 203984 (office hours) +264 81 407 1421 (After hours) Fax: +264 64 203984 Cell: +264 81 407 1421 Email: walvisbay@sec.com.na  2 000 Litre AVGAS tank 10 000 Litre AVGAS Torpedo 14 000 Litre Jet A1 tanks 30 000 Litre Jet A1 Container Tank
4.	<i>De-icing facilities</i>	Nil info
5.	<i>Hangar space for visiting aircraft</i>	Nil info
6.	<i>Repair facilities for visiting aircraft</i>	Nil info
7.	<i>Remarks</i>	Nil info

### FYLZ AD 2.5 PASSENGER FACILITIES

1.	<i>Hotels</i>	In town
2.	<i>Restaurants</i>	In town
3.	<i>Transportation</i>	Nil
4.	<i>Medical facilities</i>	Hospital in town
5.	<i>Bank and post office</i>	In town
6.	<i>Tourist office</i>	In town
7.	<i>Remarks</i>	Nil

### FYLZ AD 2.6 RESCUE AND FIRE FIGHTING SERVICES

1.	<i>AD category for fire fighting</i>	CAT 4
2.	<i>Rescue Equipment</i>	1 vehicle, 6200 Litres of water, 750 Litres foam, 135kg DCP

### FYLZ AD 2.18 ATS COMMUNICATION FACILITIES

<i>Service designation</i>	<i>Call sign</i>	<i>Frequency</i>	<i>Hours of operation</i>	<i>Remarks</i>
<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>
TWR	Luderitz Tower	118.6MHz	MON-FRI: 0600-1500 SAT: 0700-1300 SUN: 0800-1200	All ACFT to BCST Luderitz TWR FREQ 118.6MHz when TWR unmanned

### FYLZ AD 2.19 RADIO NAVIGATION AND LANDING AIDS

<i>Type of aid, CAT of ILS/MLS (for VOR/ILS/MLS give VAR)</i>	<i>ID</i>	<i>Frequency</i>	<i>Hours of Operation</i>	<i>Position of transmitting antenna coordinates</i>	<i>Elevation of DME transmitting antenna</i>	<i>Remarks</i>
<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>
VOR/DME (17°W / 2016)	LZV	115.6 MHz CH 103X	H24	264057.20S 0151448.23E	492FT	NIL

### FYLZ AD 2.20 LOCAL TRAFFIC REGULATIONS

#### 1. Aerodrome regulations

1.1 All pilots operating at Luderitz aerodrome must wear a lime green reflective jacket depicting their airlines concerned on the rear of the jacket for safety reasons as well as easy identification

#### 1.2 Circuit Altitude:

- a) Turbine powered aircraft 2000 FT AMSL
- b) Reciprocating Engine powered aircraft  
1500 FT AMSL

#### 2. Taxiing to and from stands

Nil

#### 3. Parking area for small aircraft (general aviation)

Parking on the apron.

#### 4. Parking area for helicopters

Nil

#### 5. Apron - Taxiing during winter conditions

Nil

#### 6. Taxiing - Limitations

Nil

#### 7. School and training flights - Technical test flights - Use of runways

Nil

#### 8. Helicopter traffic - Limitation

Nil

#### 9. Removal of disabled aircraft from runways

Nil

---

## FYLZ AD 2.21 NOISE ABATEMENT PROCEDURES

Not applicable.

## FYLZ AD 2.22 FLIGHT PROCEDURES

1. Radio Communication failure:
  - a) Aircraft to join overhead the aerodrome at 2500 FT AMSL.
  - b) Observe and join the aerodrome TFC.
  - c) Make all turns to the left whenever possible.
  - d) Watch for ATC light signals from the TWR.
  - e) Land as soon as possible and report to the ATC.

2. Circuits patterns during ATC HOD:

RWY 22/04: All ACFT can expect to fly circuits to the east.

RWY 22 Left - hand circuits

RWY 04 Right - hand circuits

## FYLZ AD 2.23 ADDITIONAL INFORMATION

NIL

## FYLZ AD 2.24 CHARTS RELATED TO LUDERITZ

	Page
Instrument Approach Chart – ICAO RNP RWY 04	AD 2-9
Database coding FYLZ RNP RWY 04	AD 2-10
Instrument Approach Chart – ICAO RNP RWY 22	AD 2-11
Database coding FYLZ RNP RWY 22	AD 2-12
Visual Approach Chart – ICAO	AD 2-13
Additional Information	AD 2-14